

Criando um Dashboard de IoT com o MQTT Dash



Professor: Luiz Felipe Oliveira





Parte 0: Explicando o MQTT Parte 1: Publicação dos Dados


Parte 2: Visualização dos Dados

Modo Station + Cloud + App


CLOUD

WIFI MODE

STATION











CLOUD

Instalando o MQTT Dash no Android








Instalando o Mqter no iOS












MQTT_BROKER: broker.hivemq.com

MQTT_PORT: 1883








Name FRJ CNIT Address broker hivemq.com Port 1883 Enable connection encryption (SSL/TLS) Notice if sever certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If sever certificate issued by a known Certificate late without friendly (CA), it will work out of box without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium Large			14:14
IFRJ CNIT Address broker.hivemq.com Port 1883 Enable connection encryption (SSL/TLS). Note: If server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't lorget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium	MC	QTT Dash	
broker.hivemq.com Port 1883 Enable connection encyption (SSL/TLS) Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Name	
broker hivemq.com Port 1883 Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		IFRJ CNIT	
Port 1883 Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Address	
Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		broker.hivemq.com	
Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Port	
Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name		1883	
User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections.	
User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		☐ This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk.	
Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		User name	
mqttdash-d5aa994b Tile size Small Medium		User password	
Tile size Small Medium		Client ID (must be unique)	
Small Medium		mqttdash-d5aa994b	
Medium			
○ Large			
		○ Large	




Name FRJ CNIT Address broker hivemq.com Port 1883 Enable connection encryption (SSL/TLS) Notice if sever certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If sever certificate issued by a known Certificate late without friendly (CA), it will work out of box without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium Large			14:14
IFRJ CNIT Address broker.hivemq.com Port 1883 Enable connection encryption (SSL/TLS). Note: If server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't lorget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium	MC	QTT Dash	
broker.hivemq.com Port 1883 Enable connection encyption (SSL/TLS) Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Name	
broker hivemq.com Port 1883 Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		IFRJ CNIT	
Port 1883 Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Address	
Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		broker.hivemq.com	
Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Port	
Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections. This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk. User name		1883	
User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		Enable connection encryption (SSL/TLS). Note: if server certificate is self-signed, you need to install it to your device or enable option below, otherwise connection will fail. If server certificate issued by a known Certificate Authority (CA), it will work out of box, without installing to you device. Also don't forget, that MQTT servers have different ports for plain and SSL/TLS connections.	
User password Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		☐ This broker uses self-signed SSL/TLS certificate. I trust this certificate at my own risk.	
Client ID (must be unique) mqttdash-d5aa994b Tile size Small Medium		User name	
mqttdash-d5aa994b Tile size Small Medium		User password	
Tile size Small Medium		Client ID (must be unique)	
Small Medium		mqttdash-d5aa994b	
Medium			
○ Large			
		○ Large	
















MQTT Dash Name Millis Topic (sub) ifrj_cnit_luizfelipe_millis	
Millis Topic (sub)	
Topic (sub)	
Topic (sub)	
ifrj_cnit_luizfelipe_millis	
Extract from JSON path (if payload is in JSON format), e.g.: \$.level.value. JSON path documentation at the URL below: https://github.com/jayway/JsonPath/blob/master/README.md	
Enable publishing	
Prefix Postfix	
Main text size	
○ Small	
○ Medium	
● Large	
Main text color	
Other settings	
QoS(0)	
OoS(1)	
O QoS(2)	


Criando o Switch do LED Red



		14:05
MC	QTT Dash	
	Name	
	Red	
	Topic (sub)	
	ifrj_cnit_luizfelipe_red	
	Extract from JSON path (if payload is in JSON format), e.g.: \$.level.value. JSON path documentation at the URL below: https://github.com/jayway/JsonPath/blob/master/README.md	
	✓ Enable publishing	
	Topic (pub) - keep empty if the same as sub	
	✓ Update metric on publish immediately (do not wait for incoming message to update visual state)	
	Payload and icons. If you need not a switch, but a simple button, just set the same payload values and the same icons for On and Off. This way the switch will never change icon and always send the same payload value.	
	On 1 Off 0	
	Other settings	
	008(1)	

Criando o Switch do LED Yellow






Criando o Switch do LED Green




		14:06
MC	QTT Dash	
	Name	
	Green	
	Topic (sub)	
	ifrj_cnit_luizfelipe_green	
	Extract from JSON path (if payload is in JSON format), e.g.: \$.level.value. JSON path documentation at the URL below: https://github.com/jayway/JsonPath/blob/master/README.md	
	✓ Enable publishing Topic (pub) - keep empty if the same as sub	
	✓ Update metric on publish immediately (do not wait for incoming message to update visual state)	
	Payload and icons. If you need not a switch, but a simple button, just set the same payload values and the same icons for On and Off. This way the switch will never change icon and always send the same payload value.	
	On 1 Off 0	
	Other settings	






Editando um componente já inserido











Professor: Luiz Felipe Oliveira