

ESP32 + Arduino IDE



Professor: Luiz Felipe Oliveira

Como eu começo?





Opção 1: Instalando o Arduino IDE





Downloads



Arduino IDE 1.8.15

The open-source Arduino Software (IDE) makes it easy to write code and upload it to the board. This software can be used with any Arduino board.

Refer to the Getting Started page for Installation instructions.

SOURCE CODE

Active development of the Arduino software is **hosted by GitHub**. See the instructions for **building the code**. Latest release source code archives are available **here**. The archives are PGP-signed so they can be verified using **this** gpg key.



https://www.arduino.cc/en/software

Arduino IDE na Loja de Aplicativos



() Usamos cookies para aprimorar sua experiência em nossos sites e para fins de publicidade. <u>Política de Privacidade</u>	Aceitar tudo Gerenciar cookies
Microsoft Página inicial Xbox Software v Jogos & Entretenimento v Pequenas Empresas Mais v	Toda a Microsoft - , \mathcal{O} $\overleftarrow{\mathbb{W}}$ $(\overrightarrow{\mathbb{A}_{b}})$
Aduino LLC • Ferramentas de desenvolvedor Aduino LLC • Ferramentas de desenvolvedor Arduson tarvare. It's intended for anyone making interactive projects. Mais	Gratuito Obter ▲ Consulte Requisitos do Sistema
<u>Visão geral</u> Requisitos do sistema Relacionado Disponível em ≌ computador	
Descrição	
Arduino is an open-source electronics platform based on easy-to-use hardware and software. It's intended for anyone making interactive projects.	
IMPORTANT: This app performs with core functionality on Windows 10 S but some limited plugins do not work. We are working with Microsoft on a fix.	
Capturas de tela	

Arduino IDE







X sketch_aug16a | Arduino 1.8.15 (Windows Store 1.8.49.0) -Arquivo Editar Sketch Ferramentas Ajuda Ctrl+N Novo Ø Ctrl+O Abrir... Abrir Recente 3 Sketchbook run once: Exemplos Fechar Ctrl+W Salvar Ctrl+S Ctrl+Shift+S Salvar como... in repeatedly: Configuração da página Ctrl+Shift+P Imprimir Ctrl+P Ctrl+Vírgula Preferências Sair Ctrl+Q v with spiffs (1.2MB APP/1.5MB SPIFFS), 240MHz (WiFi/BT), QIO, 80MHz, 4MB (32Mb), 921600, None em COM3

referências		×
Configurações Rede		
Local do Sketchbook:		
C: \Users \luizo \Documents \Arduino	Navegador]
Idioma do editor: System Defa	ult v (requer reinicialização do Arduino)	
Tamanho da fonte do editor: 12		
Escala de interface: 🛛 Automátic	co 100 🗘 % (requer reinicialização do Arduino)	
Theme: Default them	e 🗸 (requer reinicialização do Arduino)	
Mostrar mensagens de saída durante: 🗌 compilação	carregar	
Avisos do compilador: Nenhum 🗸		
Mostrar números de linhas	Habilitar Dobramento de Código	
Verificar código depois de carregar	Usar editor externo	
🗹 Checar atualizações ao iniciar	Salve ao verificar ou carregar	
Use accessibility features		
URLs Adicionais para Gerenciadores de Placas	ps://dl.espressif.com/dl/package_esp32_index.json	
Mais preferências podem ser editadas diretamente n		
C: \Users \uizo \Documents \ArduinoData \preferences	txt	
(editar apenas quando o Arduino não estiver em exe	cução)	
	OK Cancelar	

INSTITUTO FEDERAL

Rio de Janeiro Campus Niterói

https://dl.espressif.com/dl/package_esp32_index.json



💿 sketch_aug16a Arduin	io 1.8.15 (Windows Store 1.8.49.0) — 🗆 🗙		
Arquivo Editar Sketch Fe	rramentas Ajuda	6	
	Autoformatação	Ctrl+T	
	Arquivar Sketch		
sketch_aug16a	Corrigir codificação e recarregar		
<pre>void setup() {</pre>	Gerenciar Bibliotecas	Ctrl+Shift+I	
// put your setu	Monitor serial	Ctrl+Shift+M	
}	Plotter serial	Ctrl+Shift+L	
<pre>void loop() {</pre>	WiFi101 / WiFiNINA Firmware Updater		
// put your main	Placa: "ESP32 Dev Module"		Gerenciador de Placas
}	Upload Speed: "921600"	1	
	CPU Frequency: "240MHz (WiFi/BT)"	\$	
	Flash Frequency: "80MHz"	2	
	Flash Mode: "QIO"	>	
	Flash Size: "4MB (32Mb)"	>	
	Partition Scheme: "Default 4MB with spiffs (1.2MB APP/1.5MB SPIFFS)"	>	
	Core Debug Level: "Nenhum"	>	
	PSRAM: "Disabled"	>	
	Porta	>	
with spiffs (1.2MB APP/1.5N	Obter informações da Placa		
	Programador	>	
	Gravar Bootloader		



spoz			
Placas incluídas ne SP32 Dev Module,	ms sse pacote: · WEMOS LoLin32, WEMO	DS D1 MINI ESP32.	
<u>More Info</u>			1.0.6 V Instalar
			2.0

Opcional: Adicionando suporte ao ESP8266

referências			2
Configurações Rede			
Local do Sketchbook:			
C: \Users\\uizo\Documents\Arduino			Navegador
(dioma do editor:	System Default	 (requer reinicialização do Arduino) 	
Tamanho da fonte do editor:	12		
Escala de interface:	Automático 100 🗘 % (requer reinicializaçã	io do Arduino)	
Theme:	Default theme 🧹 (requer reinicialização do Ardu	ino)	
lostrar mensagens de saída durante	: 🗌 compilação 📃 carregar		
Avisos do compilador:	Nenhum 😼		
Mostrar números de linhas	Hab	ilitar Dobramento de Código	
Verificar código depois de carreg	ar 🗌 Usa	r editor externo	
🗹 Checar atualizações ao iniciar	Salv	e ao verificar ou carregar	
Use accessibility features			
JRLs Adicionais para Gerenciadores	e Placas http://arduino.esp8266.com/s	table/package_esp8266com_index	.json
Mais preferências podem ser editada	s diretamente no arquivo		
C: \Users\uizo\Documents\ArduinoDa	ta\preferences.txt		
editar apenas quando o Arduino nã	estiver em execução)		
			OK Cancelar

INSTITUTO FEDERAL

Rio de Janeiro Campus **Niterói**

http://arduino.esp8266.com/stable/package_esp8266com_index.json

Opcional: Adicionando suporte ao ESP8266

Tipo Todos

esp8266

Online Help More Info





	Autoformatação	Ctrl+T		
	Arquivar Sketch			
etch_aug16a	Corrigir codificação e recarregar			
i setup() {	Gerenciar Bibliotecas	Ctrl+Shift+I	-	<u> </u>
' put your setu	Monitor serial	Ctrl+Shift+M		ESP32 Dev Module
	Plotter serial	Ctrl+Shift+L	-	ESP32 Wrover Module
	WEI101 / WEINING Engineer Underen			ESP32 Pico Kit
i loop() {				TinyPICO
put your main	Placa: "ESP32 Dev Module"	;	Gerenciador de Placas	S.ODI Ultra v1
	Upload Speed: "921600"	3	Arduino AVR Boards	MagicBit
	CPU Frequency: "240MHz (WiFi/BT)"	3	ESP32 Arduino	Turta IoT Node
	Flash Frequency: "80MHz"	3	ESP8200 Boards (3.0.2)	TTGO LoRa32-OLED V1
	Flash Mode: "QIO"	>		TTGO T1
	Flash Size: "4MB (32Mb)"	>		TTGO T7 V1.3 Mini32
i i i i i i i i i i i i i i i i i i i	Partition Scheme: "Default 4MB with spiffs (1.2MB APP/1.5MB SPIFFS)"	>		TTGO T7 V1.4 Mini32
	Core Debug Level: "Nenhum"	>		XinaBox CW02
	PSRAM: "Disabled"	>		SparkFun ESP32 Thing
	Porta	>		SparkFun ESP32 Thing Plus
	Obter informações da Placa			u-blox NINA-W10 series (ESP32)
offs (1.2MB APP/1.5M	Dragmander	×		Widora AIR
	Programador	· ·		Electronic SweetPeas - ESP320
				Nano32
				LOLIN D32
				LOUIN D32 PRO

Drivers

















CH340



CP210x Drivers



Download and Install VCP Drivers

Downloads for Windows, Macintosh, Linux and Android below.

*Note: The Linux 3.x.x and 4.x.x version of the driver is maintained in the current Linux 3.x.x and 4.x.x tree at www.kernel.org.

Software Downloads

Software (10)

Software • 10

CP210x Universal Windows Driver	v10.1.10 1/13/2021
CP210x VCP Mac OSX Driver	3/31/2021
	v6.7.6
CP210x Windows Drivers	9/3/2020
	v6.7.6
CP210x Windows Drivers with Serial Enumerator	9/3/2020
	5/5/2020
CP210x_5x_AppNote_Archive	9/3/2020

Show 5 more Software

Legacy OS Software Versions

Driver Package download links and support information

Serial Enumeration Driver

What is the serial enumeration driver and why would I need it?

https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers

CP210x Drivers





The CH340 chip is used by a number of Arduino compatible boards to provide USB connectivity, you may need to install a driver, don't panic, it's easier than falling off a log, and much less painful.

Windows

(Manufacturer's Chinese Info Link)

Download the Windows CH340 Driver

onzip the nie

- · Run the installer which you unzipped
- In the Arduino IDE when the CH340 is connected you will see a COM Port in the Tools > Serial Port menu, the COM number for your device may vary depending on your system.

https://sparks.gogo.co.nz/ch340.html

Revisão



Arduino IDE URLs Adicionais para Gerenciadores de **Placas** Adição do suporte à placa ESP32 Instalação do Driver

	Autoformatação	Ctrl+T		ø
	Arquivar Sketch			_
WIFI_Kit_32_Factory	Corrigir codificação e recarregar			
Heltec.displ	Gerenciar Bibliotecas	Ctrl+Shift+I	FT RITU ODENLOF "."+".	
delay(10);	Monitor serial	Ctrl+Shift+M	ri_Non_oren(): (),	
}	Plotter serial	Ctrl+Shift+L		
3	WiFi101 / WiFiNINA Firmware Updater			
Heltec.display -	Placa: "Heltec WiFi LoRa 32"	>	>	
Heltec.display -	Upload Speed: "921600"	>	,	
	CPU Frequency: "240MHz (WiFi/BT)"	>	»	
	Core Debug Level: "Nenhum"	>	>	
oid setup()	PSRAM: "Disabled"	>	»	
	LoRaWan Region: "REGION_EU868"	>	•	
pinMode (LED, OUTF	LoRaWan Debug Level: "Nenhum"	>	>	
digitalwirte (BED	Porta: "COM3"	2	Portas seriais	
Heltec.begin(tru	Obter informações da Placa		COM3 (1 Enable*/);	
logo();	Programador	>	»	
delay(300);	Gravar Bootloader			
<pre>delay(300); Heltec.display->cr</pre>	Gravar Bootloader			
<pre>delay(300); Heltec.display->>> WIFISetUp();</pre>	Gravar Bootloader			
<pre>delay(300); Heltec.display->cr WIFISetUp(); WiFi.disconnect(tr</pre>	Gravar Bootloader ue);//重新初始化WIFI			
<pre>delay(300); Heltec.display-> WIFISetUp(); WiFi.disconnect(tr delay(1000); WiFi ===================================</pre>	Gravar Bootloader ue);//重新初始化WIFI			
<pre>delay(300); Heltec.display->>> WIFISetUp(); WiFi.disconnect(tr delay(1000); WiFi.mode(WIFI_STA WiFi.setAutoConnec</pre>	Gravar Bootloader ue)://重新初始化WIFI); (true):			
<pre>delay(300); Heltec.display->cx WIFISetUp(); WIFi.disconnect(tr delay(1000); WIFi.mode(WIFI_STA WIFi.setAutoConnect)</pre>	Gravar Bootloader certy; ue);//重新初始代WIFI); t(true);			
<pre>delay(300); Heltec.display->cx WIFISetUp(); WIF1.disconnect(tr delay(1000); WIF1.mode(WIFI_STA WIF1.setAutoConnect WIF1.setAutoConnect</pre>	Gravar Bootloader cer (); ue);//重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->cr WIFISetUp(); WIFI.disconnect(tr delay(1000); WIFI.mode(WIFI_STA WIFI.setAutoConnec sid loop()</pre>	Gravar Bootloader ue);//重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->cs WIFISetUp(); WIFI.disconnect(tu delay(1000); WIFI.setAutoConnec vid loop() WIFIScan();</pre>	Gravar Bootloader ue);//重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->co WIFISetUp(); WIF1.disconnect(tr delay(1000); WIF1.setAutoConnec oid loop() WIFIScan(); delay(5000);</pre>	Gravar Bootloader ue);//重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->com WIFIsetUp(); WIFi.disconnect(tr delay(1000); WIFI.med(WIFI_STR WIF1.setAutoConnect bid loop() WIFIScan(); delay(5000);</pre>	Gravar Bootloader ue)://重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->cs WIFISetUp(); WiFi.disconnect(tt delay(1000); WIFI.mode(WIFI_STA WIFi.setAutoConnect did loop() WIFIScan(); delay(5000); arregado.</pre>	Gravar Bootloader ue);//重新初始化WIFI); t(true);			
<pre>delay(300); Reltec.display->cs WIFISetUp(); WIFI.disconnect(tt delay(1000); WIFI.setAutoConnect vid loop() WIFIScan(); delay(5000); wIFIScan(); delay(5000);</pre>	Gravar Bootloader ue)://重新初始化WIFI); t(true);			
<pre>delay(300); Heltec.display->r WiFisetUp(); WiFi.delay(1000); WiFi.mode(WIFI_STA WiFi.setAutoConnec oid loop() WiFiScan(); delay(5000); mregado. aving of secontary of a Table State of State</pre>	Gravar Bootloader ue)://重新初始化WIFI); t(true);			

Opção 2: Arduino Web Editor





Opção 2: Arduino Web Editor



	×	SimpleWiFiServer UPGRADE PLAN	8 🌖
> EDITOR	NEW SKETCH 🛅 🗘	✓ → ★ ESP32 Dev Module	
Sketchbook	SEARCH SKETCHBOOK Q	SimpleWiFiServer.ino	
Examples	ORDERING BY LAST MODIFIED	1 * /* 2 WiFi Web Server LED Blink	K 3
Libraries	AP_SimpleWebServer_copy	A simple web server that lets you blink an LED via the web. This sketch will print the IP address of your WiFi Shield (once connected) to the Serial monitor. From there, you can open that address in a web browser	ΣΞ
्र- Monitor	🖬 sketch_aug16a	7 to turn on and off the LED on pin 5. 8 9 If the IP address of your shield is yourAddress:	
Reference		10 http://yourAddress/L turns the LED on 11 http://yourAddress/L turns it off	
⑦ Help		12 13 This example is written for a network using WPA encryption. For 14 WEP or WPA, change the Wifi.begin() call accordingly. 15	
簾¦ Preferences		16 Circuit: 17 * WiFi shield attached	
C Features usage		<pre>18 * LED attached to pin 5 19 20 created for anduino 25 Nov 2012 21 by Tom Igoe 22 23 ported for sparkfun esp32 24 31.01.2017 by Jan Hendrik Berlin 25 26 */ 27 28 #include <wifi.h> 29 20 const char* ssid = "yourssid"; 21 const char* ssid = "yourpasswd"; 23 34 WiFiServer server(80); 34 35 void setup() 36 * / </wifi.h></pre>	





https://create.arduino.cc/getting-started/plugin/download

INSTITUTO FEDERAL
 Rio de Janeiro
 Campus
 Niterói





GO TO WEB EDITOR

INSTITUTO FEDERAL

Rio de Janeiro Campus **Niterói** Revisão

INSTITUTO FEDERAL Rio de Janeiro Campus Niterói

CANCEL

Select Other Board & Port

Select both a BOARD and a PORT if you want to upload a sketch.

If you only select a BOARD you will be able just to compile,

but not to upload your sketch.

BOARDS		PORTS	
esp32 dev	Q	COM5	~
DOIT ESP32 DEVKIT V1		FLAVOURS	- 1
ESP32 Dev Module	~	Default 4MB with spiffs (1.2MB A	-
Hornbill ESP32 Dev		240MHz (WiFi/BT)	-
Onehorse ESP32 Dev Module		QIO	•
VintLabs ESP32 Devkit		80MHz	•

Arduino Web Editor + Arduino CREATE Agent + Instalação do Driver



Dúvidas



Professor: Luiz Felipe Oliveira